

AIR CLEANER FILTER




Inspection guideline (Replace if necessary)

	Interval	
6,000 km	1 year	*whichever comes first

^{*}This guideline may vary by motorcycle model, condition of use, region, etc. Please refer to the owner's manual or ask an authorized Suzuki dealer for more information.

Purpose and Function

The air cleaner filter removes dust and other contaminant particles from the air that is sucked into the engine.





If overused without replacement ...

- · Hard to start the engine
- · Decrease in engine power
- · Decrease in fuel economy
- Engine parts wear
- Weakens throttle response

An excessively contaminated air cleaner filter reduces the air flow to the engine cylinder. This may cause the engine to malfunction, such as incomplete combustion and an increase in fuel consumption.

In addition, if the filter performance has been compromised, dust and other contaminants enter the engine cylinder, which can lead to the premature wear of internal components.